

Deluxe Tambour Doors Fixing Instructions

PWS



1 Position the roller mounting brackets to top of cabinet and 22 mm back from edge of cabinet. The track can be used as a guide, secure with 5 x countersunk screws provided.



2 Remove protective foam and re roll tambour tightly but with care to avoid scratching, secure with a rubber band. Fit tambour into the mounting bracket



3 Locate tracks in position covering front edge using self adhesive tape and secure trough rear flange with pan head screws provided.



4 Locate fascia to top of cabinet using self adhesive tape and secure with pan head screws provided.



5 Fit top and bottom cover strips using self adhesive tape only.



6 Fit idler roller into roller mounting bracket. Smear petroleum jelly provided on the inside of the track to ensure smooth running.



9 Fit handle from PWS range (not supplied with this kit)



8 Feed the tambour over the idler and down the track.



7 Ensuring the flats are engaged. Cut the rubber band and rotate the shutter half a turn in the direction of the arrow.

DELUXE KIT CONTENTS

Tambour	1
Roller Mounting Bracket	1 pair
Track	1 pair
Fascia	1
Cover Strips	2
Idler Roller	1
C/sunk Screws	10
Pan Head screws	14
Sachet Petroleum Jelly	1

Cleaning / Maintenance

Use non-abrasive cleaning products only on a soft cloth

10 Test operation of shutter.

DISTRIBUTED BY:
PWS
P.O. Box 20, Station Road
Aycliffe Industrial Park
Newton Aycliffe
Co. Durham
DL5 6XJ

Tel: 01325 50 55 55
Fax: 01325 50 55 00
Email: mail@pws.co.uk

MANUFACTURED BY:
Rotalac Plastics Ltd
Canal Road
Timperley
Altrincham
Cheshire
WA14 1TB

Tel: 0161 928 6411
Fax: 0161 927 7856
Email: enq@rotalac.com
Website: www.rotalac.com

Re-order ref: PWS0002
(Instruction sheet only)

WARNING: Do not apply adhesive tape to any of the stainless steel surfaces as it can leave unsightly permanent marks.

Made in Great Britain

